




**PREMIUM
LINE** _____

MANUAL




Air extractors are essential components for ensuring proper air circulation and ventilation within enclosed spaces.

The product is only installed on 12.5mm gypsum boards.


Q(m³/h)	50-200
---------------------------	--------

Package includes the following parts:


- a** AIR EXTRACTOR




1x
- b** ASSEMBLY & INSTALLATION SCREWS 35mm




8x
- c** SPIGOT SCREWS 20mm




4x
- d** VENTUS SPIGOT


- e** FIBERGLASS




1 ASSEMBLY INSTRUCTIONS


Step 1




Step 2



Step 3




Step 4




2 INSTALLATION

Step 1




Step 2




3 FINISHING PROCESS


Step 1




Step 2




Step 3




Step 4



Step 5




Step 6




DISASSEMBLY INSTRUCTIONS


Step 1




Step 2




Step 3




Step 4



Step 5



Step 6



Give Your Product a New Life!

All D.Ellinas products are designed to be disassembled for either reuse or recycling.

www.wcvent.com

Copyright © WCvent Air Extractors® is a brand of D.Ellinas Factory Products Ltd®, protected by European and International laws pertaining to intellectual property.

D.Ellinas Factory Products is a registered company in Cyprus (reg. no. HE260375)